SONOFF

SNZB-02P

Quick Guide V1.4

Zigbee Temperature and Humidity Sensor

1

EN: Download the eWeLink App & Add SONOFF Zigbee gateway
DK: Download eWeLink-appen og tilføj SONOFF Zigbee-gateway
SE: Ladda ner eWeLink-appen och lägg till SONOFF Zigbee-gateway
DE: Laden Sie die eWeLink App herunter und fügen Sie das SONOFF Zigbee-Gateway hinzu
NL: Download de eWeLink App en voeg SONOFF Zigbee gateway toe

2

EN: Scan QR Code to Add Device
DK: Scan QR koden for at tilføje enheden
SE: Skanna QR-koden för att lägga till en enhet
DE: Den QR-Code scannen, um Gerät hinzuzufügen
NL: Scan QR-code om apparaat toe te voegen



2

EN: Open the eWeLink App and scan the QR code on the device, then follow the instructions given by the app to proceed.

DK: Åben eWeLink appen og scan QR koden på enheden, følg derefter indstrukserne fra appen for at fortsætte

SE: Öppna eWeLink App och skanna QR-koden på enheten, följ sedan instruktionerna från appen för att fortsätta.

DE: Öffnen Sie die eWeLink App, scannen Sie den QR-Code auf dem Gerät und folgen Sie dann den Anweisungen der App.

NL: Open de eWeLink App en scan de QR code op het apparaat, volg daarna de instructies dat door de app worden gegeven om verder te gaan.

3

Note: If the desired page cannot be displayed after scanning the QR code, please power on the device, then click the Zigbee gateway of the device that you want to add in the eWeLink App and select "Add".

Bemærk: Hvis siden ikke vises efter scanning af koden, skal du tænde enheden, og vælg den Zigbee gateway som du ønsker at tilføje i eWeLink appen og vælg "tilføj"

Obs: Om den önskade sidan inte kan visas efter att ha skannat QR-koden, slå på enheten, klicka sedan på Zigbee-gatewayen för enheten som du vill lägga till i eWeLink App och välj "Lägg till"

Hinweis: Wenn die gewünschte Seite nach dem Scannen des QR-Codes nicht angezeigt werden kann, schalten Sie bitte das Gerät ein, klicken Sie dann auf das Zigbee-Gateway des Geräts, das Sie in der eWeLink App hinzufügen möchten, und wählen Sie "Hinzufügen".

Noteer: Als de gewenste pagina niet kan worden weergegeven na het scannen van de QR-code, schakel dan het apparaat in, klik vervolgens op de Zigbee-gateway van het apparaat dat u wilt toevoegen in de eWeLink App en selecteer "Toevoegen".

3

EN: Effective Communication Distance Verification
SE: Effektiv fjärrstyrning af kommunikation
DE: Verifizierung der effektiven Kommunikationsentfernung
NL: Controle van de effectieve communicatieafstand

EN: Install the device in the desired place, then press the Pairing button on the device. The LED indicator flashes twice means the device and the device are in the same Zigbee network (the router device or hub) are in the effective communication distance

DK: Installer enheden på det ønskede sted, og tryk derefter på Parring knappen på enheden. Hvis LED-indikatoren blinker to gange betyder det at enheden og (routerenheden eller hubben) er i den effektive kommunikation afstand

5

SE: Installera enheten på önskad plats och tryck på "parkopplingsknappen"på enheten. När du ser LED-indikatorn blinka två gånger betyder det att den här enheten och enheterna (routern eller navenheterna) under samma Zigbee nätverk har ett effektivt kommunikationsavstånd.

DE: Installieren Sie das Gerät am gewünschten Ort und drücken Sie dann die Taste Kopplungstaste am Gerät. Der LED-Anzeiger blinkt zweimal, wenn sich das Gerät und das Gerät im selben Zigbee-Netzwerk (Router oder Hub) in einer effektiven Kommunikationsentfernung befinden.

NL: Installeer het apparaat op de gewenste plaats en druk op de „koppelingsknop" op het apparaat. Als je de LED indicator tweemaal ziet knipperen, betekent dit dat dit apparaat en de apparaten (de router apparaten of hub) onder hetzelfde Zigbee netwerk binnen de effectieve communicatieafstand zijn.

6

4

EN: Installation
DK: Installation
SE: Installation
DE: Installation
NL: Installatie

EN: Fix the metal plate in a desired location, and then magnetically attach the device to the plate.

DK: Fastgør metalpladen til det ønskede sted, og fastgør derefter enheden magnetisk på pladen.

SE: Fäst metallplattan på önskad plats och fäst sedan enheten magnetiskt på plattan

DE: Befestigen Sie die Metallplatte an einem gewünschten Ort und bringen Sie das Gerät dann magnetisch an der Platte an.

NL: Bevestig de metalen plaat op een gewenste locatie, en bevestig vervolgens het apparaat magnetisch aan de plaat.

7

5

EN: Replace the Battery
DK: Udskrifning af batteri
SE: Byt ut batteriet
DE: Auswechseln der Batterie
NL: De batterij vervangen

EN: Use a card ejector pin to press the buckle and use a coin or other tool to rotate the bottom cover, then pry open the bottom cover

DK: Brug en stift til at trykke på låsen, og brug samtidig en mønt eller et andet værktøj til at dreje bunddækslet, og vip derefter dækslet op.

SE: Använd en kortutskjutare för att trycka på spännet och använd ett samtidigt som du mynt eller annat verktyg för att rotera bottenlocket och bänd sedan upp bottenlocket.

8

DE: Drücken Sie mit einem Kartenauswurfstift auf die Schnalle, und gleichzeitig drehen Sie die untere Abdeckung mit einer Münze oder einem anderen Werkzeug und heben Sie die untere Abdeckung auf.

NL: Gebruik een kaartuitwerpen om de sluiting in te drukken en gebruik op hetzelfde moment een munt of ander gereedschap om het bodemdeksel te draaien, wrik vervolgens het bodemdeksel open.

User Manual

https://sonoff.tech/usermanuals

EN: Enter the website provided above to view the User Manual for the device.
DK: Gå ind på hjemmesiden ovenfor for at se brugervejledningen til enheden.
SE: För åtkomst till enhetens användarmanual, gå till URL:en ovan.
DE: Auf das Benutzerhandbuch des Geräts zuzugreifen, rufen Sie die oben aufgeführte URL auf.
NL: Ga voor toegang tot de gebruikershandleiding van het apparaat naar de bovenstaande URL.

9

EN

WARNING

- Do not swallow battery. Chemical Burn Hazard.
- This product contains a coin / button cell battery if the coin / button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
- Keep new and used batteries away from children.
- If the battery compartment does not close securely, stop using the product and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
- Do not replace a battery with an incorrect type.
- Replacement of a battery with an incorrect type that can defeat a safeguard (for example, in the case of some lithium battery types).
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
- Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

DK

WARNING

- Må ikke indtages - Fare for kemisk forbrændinger.
- Dette produkt indeholder en mønt-/knapcellebatteri. Hvis batteriet sluges, kan det forårsage alvorlige indre forbrændinger på blot 2 timer og kan føre til livstruende.
- Hold nye og brugte batterier væk fra børn.
- Hvis batterirummet ikke lukker forsvarligt, skal produktet ikke anvendes og holdes uden for børns rækkevidde.
- Hvis du har mistanke om, at et batteri er blevet slugt eller indført i kroppen, skal der straks søges lægehjælp.
- Udskift ikke batteriet med en forkert type.
- Udskiftning med en forkert batteritype kan omgå sikkerhedsforanstaltninger (for eksempel i tilfælde af visse typer litiumbatterier).
- Bortskaffelse af et batteri i ild eller en varm ovn, eller mekanisk knusning eller skæring af et batteri, kan føre til eksplosion.
- Efterlades et batteri i omgivelser med ekstremt høj temperatur, kan det medføre eksplosion eller lækage af brandfarlig væske eller gas.
- Et batteri udsat for ekstremt lavt luftryk kan medføre eksplosion eller lækage af brandfarlig væske eller gas.

11

SE

VARNING

- Batteriet ska inte förtäras, risk för kemisk brännskada.
- Denna produkt innehåller ett mynt/knappcellsbatteri. Om mynt-/knappcellsbatteriet sväljs kan det orsaka allvarliga invärtes brännskador på bara två timmar och leda till döden.
- Förvara nya och använda batterier utom räckhåll för barn.
- Om batterifyrrummet inte kan stängas ordentligt ska du sluta använda produkten och förvara den utom räckhåll för barn. Om du misstänker att du har intagit batterier har svalts eller placerats inuti kroppen

DE

WARNUNG

- Batterie nicht verschlucken – Gefahr von Verätzungen durch Chemikalien
- Dieses Produkt enthält eine Knopf-/Knopfzellenbatterie. Wenn die Knopf-/Knopfzellenbatterie verschluckt wird, kann sie in nur 2 Stunden schwere innere Verbrennungen verursachen und zum Tod führen.
- Halten Sie neue und gebrauchte Batterien von Kindern fern.
- Wenn sich das Batteriefach nicht sicher schließen lässt, stellen Sie die Verwendung des Produkts ein und halten Sie es von Kindern fern. Wenn Sie glauben, dass Batterien verschluckt oder in einen Körperteil eingeführt worden sein könnten, suchen Sie sofort einen A

NL

WAARSCHUWING

- De batterij niet inslikken, gevaar voor chemische brandwonden.
- Dit product bevat een knoopcellabatterij. Als de knoopcellabatterij wordt ingeslikt kan dit in slechts 2 uur ernstige interne brandwonden veroorzaken en kan de dood tot gevolg hebben.
- Houd nieuwe en gebruikte batterijen uit de buurt van kinderen.
- Als het batterijvakje niet goed dicht, stop dan met het gebruik van het product en houd het uit de buurt van kinderen. Als u denkt dat batterijen zijn ingeslikt of in een deel van het lichaam zijn geplaatst, zoek dan onmiddellijk medische hulp.

12

FCC compliance statement:

1.This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. 2.Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: —Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. —Consult the dealer or an experienced radio/TV technician for help. FCC Radiation Exposure Statement: This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.

WEEE Disposal and Recyling Information

All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handingover your waste equipment to a designated collection point for the recycling of waste electricaland electronic equipment, appointed by the government or local authorities. Correct disposaland recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about thelocation as well as terms and conditions of such collection points.

13

ISED Notice

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1)This device may not cause interference. (2)This device must accept any interference, including interference that may cause undesired operation of the device. This Class B digital apparatus complies with Canadian ICES-003(B). This device complies with RSS-247 of Industry Canada. Operation is subject to the condition that this device does not cause harmful interference. L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1)L'appareil ne doit pas produire de brouillage; (2)L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. Cet appareil numérique de la Classe B conforme à la norme NMB-003(B) du Canada. Cet appareil est conforme à la norme RSS - 247 d'Industrie Canada. Le fonctionnement est soumis à la condition que cet appareil ne provoque pas d'interférences nuisibles. ISED Radiation Exposure Statement This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body. Cet équipement doit être installé et fonctionner à au moins 20cm de distance d'un radiateur ou de votre corps

EU Declaration of Conformity

Hereby, Shenzhen Sonoff Technologies Co., Ltd. declares that the radio equipment type SNZB-02P is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: https://sonoff.tech/compliance/

Warning

Under normal use of condition, this equipment should be kept a separation distance of at least 20 cm between the antenna and the body of the user

14

For CE Frequency

Operation Frequency Range	EU Output Power
Zigbee: 2405~2480MHz	Zigbee: ≤10dBm

Instructions for Use of Low-Power Device:

1.This product utilizes Zigbee technology, which complies with the technical specifications for Category F general-purpose low-power devices listed in the "Directory and Technical Requirements for Low-Power Short-Range Radio Transmitting Equipment," and is intended for data transmission applications. An integrated antenna is used. For operation, adjustment, and switching instructions, please refer to the product manual.
2.It is strictly prohibited to alter the application scenarios or operating conditions without authorization, expand the transmission frequency range, increase transmission power (including the addition of RF power amplifiers), or modify the transmitting antenna without approval.
3.This device must not cause harmful interference to other legally operated radio stations, nor can it claim protection from such interference.
4.It must tolerate interference from industrial, scientific, and medical (ISM) equipment emitting radio frequency energy, as well as from other legal radio stations.
5.If this device causes harmful interference to other legal radio stations, usage must cease immediately, and the issue must be resolved before resuming use.
6.When using low-power devices inside aircraft or within electromagnetic protection zones of radio astronomy observatories, weather radar stations, satellite earth stations (including telemetry, tracking, receiving, and navigation stations), or military and civilian radio stations and airports, users must comply with electromagnetic protection regulations and the requirements of relevant authorities.
7.The use of all types of model remote controllers is prohibited within a 5000-meter radius from the center point of an airport runway.

15

Maintenance

The product must be maintained (cleaned) regularly either by the user or by specialized service centers, at the user's own expense and responsibility. If the user manual does not specify required maintenance, cleaning, or service intervals, the physical condition of the product should be assessed at least once a week for any deviations from that of a new product. If any deviation is detected or observed, immediate maintenance (cleaning) or servicing must be carried out. Failure to maintain (clean) the product properly and respond when a deviation is identified may result in permanent damage to the product. The manufacturer is not liable for damage caused by negligence.

Environmental protection

Used electronic equipment marked in accordance with the European Union directive must not be disposed of together with other household waste. It is subject to separate collection and recycling at designated collection points. By ensuring proper disposal, you help prevent potential negative consequences for the natural environment and human health. The waste collection system for used equipment complies with local environmental protection regulations regarding waste disposal. For more detailed information, please contact your local municipal office, waste disposal service, or the store where the product was purchased.

The product complies with the requirements of the so-called New Approach Directives of the European Union (EU), which relate to issues concerning user safety, health protection, and environmental protection. These directives define the risks that must be identified and eliminated.

16

Precautions

- Before switching on, check whether the device's contacts are clean.
- Do not leave the device unattended while in use.
- Ensure that in an emergency, the device can be quickly disconnected from the power source.
- Never expose the device to high temperatures.
- Keep the device in a dry and well-ventilated place, away from flammable materials and other objects.
- Never cover the device while it is operating.
- Never use a power adapter, charging station, cables, etc., without the manufacturer's recommendation and certification.
- The device may be equipped with cells that are difficult to extinguish – consider having a fire blanket available.
- Detailed warranty conditions are available at: sonoff.tech

Detailed information about the warranty conditions is available on the website: sonoff.tech

At And

Shenzhen Sonoff Technologies Co., Ltd.
3F & 6F, Bldg A, No. 663, Bulong Rd, Shenzhen, Guangdong, China
ZIP code: 518000 Website: sonoff.tech
Service email: support@itead.cc
MADE IN CHINA

17

UL 4200A compliance statement

WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours.**
- KEEP new and used batteries **OUT OF REACH of CHILDREN.**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body

- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- Even used batteries may cause severe injury or death.
- Call a local poison control center for treatment information .
- Compatible battery type: CR2450
- Nominal battery voltage: 3V
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat above 60°C or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
- Ensure the batteries are installed correctly according to polarity(+ and -)
- Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
- Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
- Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

18